

JIS配列 PS/2 キーボード スキャンコード表

英数字・記号・キー

通常		シフト		スキャンコード	
キー	ASCII	キー	ASCII	押す	離す
1	31	!	21	16	F0, 16
2	32	~	22	1E	F0, 1E
3	33	#	23	26	F0, 26
4	34	\$	24	25	F0, 25
5	35	%	25	2E	F0, 2E
6	36	&	26	36	F0, 36
7	37	'	27	3D	F0, 3D
8	38	(28	3E	F0, 3E
9	39)	29	46	F0, 46
0	30	—	—	45	F0, 45
a	61	A	41	1C	F0, 1C
b	62	B	42	32	F0, 32
c	63	C	43	21	F0, 21
d	64	D	44	23	F0, 23
e	65	E	45	24	F0, 24
f	66	F	46	2B	F0, 2B
g	67	G	47	34	F0, 34
h	68	H	48	33	F0, 33
i	69	I	49	43	F0, 43
j	6A	J	4A	3B	F0, 3B
k	6B	K	4B	42	F0, 42
l	6C	L	4C	4B	F0, 4B
m	6D	M	4D	3A	F0, 3A
n	6E	N	4E	31	F0, 31
o	6F	O	4F	44	F0, 44
p	70	P	50	4D	F0, 4D
q	71	Q	51	15	F0, 15
r	72	R	52	2D	F0, 2D
s	73	S	53	1B	F0, 1B
t	74	T	54	2C	F0, 2C
u	75	U	55	3C	F0, 3C
v	76	V	56	2A	F0, 2A
w	77	W	57	1D	F0, 1D
x	78	X	58	22	F0, 22
y	79	Y	59	35	F0, 35
z	7A	Z	5A	1A	F0, 1A
—	2D	=	3D	4E	F0, 4E
~	5E	~	7E	55	F0, 55
¥	5C		7C	6A	F0, 6A
@	40	↓	60	54	F0, 54
[5B	{	7B	5B	F0, 5B
:	3B	+	2B	4C	F0, 4C
:	3A	*	2A	52	F0, 52
]	5D	}	7D	5D	F0, 5D
,	2C	<	3C	41	F0, 41
.	2E	>	3E	49	F0, 49
/	2F	?	3F	4A	F0, 4A
\	5C	_	5F	51	F0, 51

ファンクション・キー

キー	ASCII	スキャンコード	
		押す	離す
F1		05	F0, 05
F2		06	F0, 06
F3		04	F0, 04
F4		0C	F0, 0C
F5		03	F0, 03
F6		0B	F0, 0B
F7		83	F0, 83
F8		0A	F0, 0A
F9		01	F0, 01
F10		09	F0, 09
F11		78	F0, 78
F12		07	F0, 07

機能キー

キー	ASCII	スキャンコード	
		押す	離す
Backspace	08	66	F0, 66
Enter	0D	5A	F0, 5A
Space	20	29	F0, 29
Esc	1B	76	F0, 76
半角/全角 漢字		0E	F0, 0E
TAB		0D	F0, 0D
CAPS		58	F0, 58
左 SHFT		12	F0, 12
左 CTRL		14	F0, 14
左 Win		E0, 1F	E0, F0, 1F
左 ALT		11	F0, 11
右 SHFT		59	F0, 59
右 CTRL		E0, 14	E0, F0, 14
右 ALT		E0, 11	E0, F0, 11
右 Win		E0, 27	E0, F0, 27
無変換		67	F0, 67
変換		64	F0, 64
カタひら ローマ字		13	F0, 13
アプリケーション		E0, 2F	E0, F0, 2F
↑		E0, 75	E0, F0, 75
↓		E0, 72	E0, F0, 72
←		E0, 6B	E0, F0, 6B
→		E0, 74	E0, F0, 74
PgUp		E0, 7D	E0, F0, 7D
PgDn		E0, 7A	E0, F0, 7A
Home		E0, 6C	E0, F0, 6C
End		E0, 69	E0, F0, 69
Delete		E0, 71	E0, F0, 71
Insert		E0, 70	E0, F0, 70
Prt Sc		E0, 12, E0, 7C	E0, F0, 7C, E0, F0, 12
Pause		E1, 14, 77, E1, FO, 14, FO, 77	無し
ScrLk		7E	F0, 7E

テンキー

キー	ASCII	スキャンコード	
		押す	離す
0	30	70	F0, 70
1	31	69	F0, 69
2	32	72	F0, 72
3	33	7A	F0, 7A
4	34	6B	F0, 6B
5	35	73	F0, 73
6	36	74	F0, 74
7	37	6C	F0, 6C
8	38	75	F0, 75
9	39	7D	F0, 7D
.	2E	71	F0, 71
/	2F	E0, 4A	E0, F0, 4A
*	2A	7C	F0, 7C
-	2D	7B	F0, 7B
+	2B	79	F0, 79
Enter	0D	E0, 5A	E0, F0, 5A
NumLk		77	F0, 77