


ビデオカメラフットリモコン(A/V リモート端子)



対応ビデオカメラ(A/V 端子・REMOTE 端子)

NEX-VG20H / PJ760V / PJ210 / PJ40V / PJ20 / CX720V
/ PJ590V / XR550V / XR520V / XR500V / XR350V /
XR150 / XR100 / CX700V / CX590V / CX560V / CX550V
/ CX520V / CX500V / CX370V / CX270V / CX180 /
CX170 / CX120 / CX12 / CX7 / HC96 / HC62 / HC48 /
HC9 / HC7 / HC3 / HC1 / FX7 / FX1000 / SX41 / SR300
/ SR220 / SR87 / SR65 / SR62 / SR12 / SR11 / SR8 /
SR7 / SR1 / VG20 / VG20H / TD20V / TG5V / TG1