

LCD to LED ASCIIコード 対 セグメント表示

		A S C I I コード 上位 4 b i t											
		0	1	2	3	4	5	6	7				
A S C I I コード 下位 4 b i t	0	CG (00)	CG (10)	0	0	@	P	`	p				
	1	CG (01)	CG (11)	!	1	A	Q	a	q				
	2	CG (02)	CG (12)	"	2	B	R	b	r				
	3	CG (03)	CG (13)	#	3	C	S	c	s				
	4	CG (04)	CG (14)	\$	4	D	T	d	t				
	5	CG (05)	CG (15)	%	5	E	U	e	u				
	6	CG (06)	CG (16)	&	6	F	V	f	v				
	7	CG (07)	CG (17)	'	7	G	W	g	w				
	8	CG (08)	CG (18)	(	8	H	X	h	x				
	9	CG (09)	CG (19)	)	9	I	Y	i	y				
	A	CG (0A)	CG (1A)	*	:	J	Z	j	z				
	B	CG (0B)	CG (1B)	+	;	K	[	k	{				
	C	CG (0C)	CG (1C)	,	<	L	¥	l					
	D	CG (0D)	CG (1D)	-	=	M	]	m	}				
	E	CG (0E)	CG (1E)	.	>	N	^	n	→				
	F	CG (0F)	CG (1F)	/	?	O	_	o	←				

* コード 00~1F ユーザーCG (キャラクタ・ジェネレータ)

Deflcdchar 0 : 00~07 Deflcdchar 1 : 08~0F

Deflcdchar 2 : 10~17 Deflcdchar 3 : 18~1F

* コード 80~FF 輝度制御 (80:暗い~FF:明るい)